

A classic item in the world of executive office chairs. Stitches in the same colour as the lining, a new range of fabrics and leathers, the two versions of the armrest and the new mechanism make it ideal to meet different stylistic requirements. The upholstery is simple yet comfortable, marked only by the seams lines on the backrest. Clear and neat signs that make it modern and stylish.

CHAIR WITH MECHANISM GYA AND  
ARMRESTS BH1  
IN CONFORMITY TO UNI EN-1335 - TYPE B

## COMPONENTS



### NEOCHAIR (EXECUTIVE CHAIR WITH HIGH AND MEDIUM BACKREST)

#### SWIVEL BASE

(ALC5) Base with 5 spokes, in die-cast aluminium, surface finishes:

- Polished aluminium in the upper part
- Black on the lower surface

Diameter 710 mm.

#### WHEELS

Self-braking black nylon wheels with diameter 50 mm and chrome-plated housing, zinc-coated steel pin, snap-fit.

Rubberized wheels optional.

(OPTIONAL) Polyamide feet interchangeable with the wheels with the same pin for fixing to the base.



#### ELEVATION

All the gas columns comply with the DIN 4550 standard and exceed the 4th level.

#### MECHANISM

- (GYA) Gas Synchron with forward pivot point

Mechanism with a synchronous seat-back movement which can be blocked in 4 positions.

With this mechanism you can:

- adjust the height of the gas piston;
- rotate the seat 360°.
- adjust load intensity based on weight;
- use the anti-shock lever to lock or unlock the synchron;



#### ARMRESTS

Available in two kinds:

- (BH1) Armrests adjustable for height; vertical square-section chromed aluminum tubular, outer coat in black polypropylene.

- (BFC1) Fixed armrests in chromed metal tubular with pad made from expanded black polyurethane.

In this kind of armrests can be use a kit (optional ART.743) of upholstered pads in matched with chair's colour.

## **SEAT**

Internal structure made from multi-layer beech-poplar wood with a 6 mm thick., covered with a 40 mm thick. non-deformable polyurethane expanded rubber with a density 35 kg/m<sup>3</sup>.

External structure made from multi-layer beech-poplar wood with a 10 mm thick., covered with a 10 mm thick. non-deformable polyurethane expanded rubber with a density 25 kg/m<sup>3</sup>.

---

## **BACKREST AND HEADREST**

Internal structure made from multi-layer beech-poplar wood with a 6 mm thick., covered with a 40 mm thick. non-deformable polyurethane expanded rubber with a density 30 kg/m<sup>3</sup>.

External structure made from multi-layer beech-poplar wood with a 10 mm thick., covered with a 10 mm thick. non-deformable polyurethane expanded rubber with a density 25 kg/m<sup>3</sup>.

---

## **UPHOLSTERY**

Check finishes and colours available in the LAS Colours Samples Card.

## DIMENSIONS



UPHOLSTERY	FEATURES	AVAILABILITY
Poli		
Ecopelle		■
Crepe		
Stretch		
Melange		
Trevi		
Lana		
Crazy by Flukso		■
Chili by Gabriel		
Taylor by Flukso		■
Go Check by Gabriel		■
Crisp by Gabriel		
Pelle		■
Customer fabric		■



SHIPPING SPECIFICATION	TECHNICAL FEATURES	FIRE-RETARDANT TEST	FABRIC RESISTANCE TEST
WITH ARMRESTS BH1			
High backrest <ul style="list-style-type: none"><li>Pcs. 1</li><li>m³ 0,547</li><li>Kg 23</li></ul>	Fabric used mtl 2,12 h.140	For specification, please you see the colour samples card. Coctact us for more information.	For specification, please you see the colour samples card. Coctact us for more information.
Medium backrest <ul style="list-style-type: none"><li>Pcs. 1</li><li>m³ 0,399</li><li>Kg 21</li></ul>	Fabric used mtl 1,80 h.140		
WITH CHROMED ARMRESTS BFC1			
High backrest <ul style="list-style-type: none"><li>Pcs. 1</li><li>m³ 0,547</li><li>Kg 24</li></ul>	Fabric used mtl 2,12 h.140		
Medium backrest <ul style="list-style-type: none"><li>Pcs. 1</li><li>m³ 0,399</li><li>Kg 22</li></ul>	Fabric used mtl 1,80 h.140		



---

## USE AND MAINTENANCE

---

### GENERAL INFORMATION

Do not expose the seating to direct sunlight and keep it at least 30 cm from any heat source;  
Do not sit with abrasive accessories, sharp objects in your pocket or jacket (keys, buttons, zippers, etc.) that may damage the fabric.  
Fabrics can fade. It may happen that under certain circumstances, colored clothes or jeans may stain the upholstery.  
Furthermore, the light colors of the fabrics and leathers are more susceptible to getting dirty.  
Choose the correct wheels for the type of floor on which the chair will be used.  
Rigid wheels on carpets or rugs (TYPE H) Soft wheels on hard ground: marble, tiles, ... etc.  
Wheels should be cleaned from time to time with gauze to remove fluff and dust.

### USE

This product is for indoor use only. The chair must be used in compliance with the aim for which it has been projected (office swivel chair) and with diligence. Improper use (e.g. climbing the chair with feet) may cause instability, falling down and/or serious injury to persons and objects.  
Do not modify the chair in a way that could compromise its stability. Gas column substitution or reparation must be performed by trained staff only.

### CLEANING AND MAINTENANCE

As a general rule, we recommend using cleaning products that do not harm the environment.  
Follow the manufacturer's instructions for cleaning products.  
Before cleaning stains, try, as far as possible, to perform a test on a hidden area.

### FABRICS

POLI - CREPE - TREVI - STRETCH - MELANGE – LANA - CRISP

For normal maintenance and cleaning, use the vacuum cleaner with smooth spout regularly, don't brush.

### TAYLOR F.R.

Use the smooth spout vacuum cleaner regularly without brushing.  
Immediately remove food residues and any oil, milk and drink stains.  
Dab quickly with absorbent paper and brush gently with water and neutral soap or 20% water and alcohol solution. **GENERAL WARNINGS**  
The remedies indicated are effective in 90% of cases. The lack of timeliness in the action makes the cleaning less effective, resulting in the permanence of halos.

### GO CHECK – CHILI - RETE ROUND – RETE BREAK – RETE GABRIEL

Use the smooth spout vacuum cleaner regularly without brushing. Immediately remove food residues and any oil, milk and drink stains.  
Dab quickly with absorbent paper and wipe gently with water and neutral soap using a clean white cotton cloth.

### ECOPELLE - CRAZY

Immediately absorb the stain with absorbent paper, then wipe with a damp cloth and neutral soap.  
Dry immediately after treatment. Do not rub, but dab gently from the edges towards the center of the stain. Repeat the operation if necessary.  
Absolutely avoid the use of products containing any type of solvents, bleaches, alcohol, chemical detergents and polishing sprays.

### PELLE (REAL LEATHER)

Possible leather scratches and marks are not to be considered imperfections but a guarantee of its quality and authenticity.  
Slight differences between dyeing lots are considered normal. For a normal cleaning, sprinkle with a soft, dry white cloth.  
Any stains can be removed using a white cloth dampened with water and neutral soap.  
After cleaning carefully, pass a damp cloth soaked in water, so as to remove any residue of detergent.  
Dry immediately after treatment. Do not rub, but dab gently from the edges towards the center of the stain.  
Do not dry in direct sunlight or with hair dryer.

### METALS (STEEL OR ALUMINIUM)

To preserve the brilliant Chrome finish, regularly wipe with a soft clean cloth using only mild soap and water.  
Do not use solvents or acids. Dry with a dry cotton cloth.  
Polished aluminium undergoes a natural oxidation process, any stains can be removed using a soft wax suitable for metals.

### PLASTIC MATERIAL

For normal maintenance and cleaning use a soft clean cloth with water and neutral soap.  
Dry with a cotton cloth. Avoid using solvents.

### PHASING OUT AND DISPOSAL OF THE PRODUCT

- At the end of their life cycle, the materials must not be left lying around in nature but consigned to the authorised disposal centres.



#### **WARRANTY**

The original buyer of LAS MOBILI s.r.l. chair unit is covered by a 5 (five) year warranty , starting from the day of purchase, with the following exceptions.  
Exposed parts such as:

Covering warranty 3 (three) years

Padding warranty 2 (two) years

The LAS MOBILI s.r.l. warranty is expressly restricted to the replacement of parts and components of the chair.

For all other aspects consult the current price list

#### **LAS MOBILI s.r.l.**

Via dell'Industria, 81  
64018 Tortoreto (TE) – Italy  
Tel. +39 0861 7831  
Fax +39 0861 786851  
[las@las.it](mailto:las@las.it) – [www.las.it](http://www.las.it)

Since the Company is constantly committed to the improvement of its products, all descriptions, dimensions, indications etc. shown on this sheet are to be considered indicative. They can therefore be subject to change without notice and without this implying any responsibility on our part or that of our dealers.